




Tommy the Robot



info@zyrobotics.com
3522 Ashford Dunwood Rd.
Suite 105 Atlanta, GA 30319
678-952-ZYRO (9976)

A Letter to Parents

“Education is the most powerful weapon which you can use to change the world.”
– Nelson Mandela

Teach kids about the wonders of coding and robotics with our new interactive social robot and coding games.

Based on Zowi and BOB, created under the Creative Commons – Attribution – Share Alike license, Tommy the Robot is an accessible robot that provides hours of coding engagement for children of all abilities.

Zyrobotics is a mix of educators and developers who have a passion for creating technology that will enhance the quality of life for children. We help younger children to understand technology, encouraging them to use it and motivating them to develop it is the fuel that powers us.

Technology rapidly transforms everything it touches. It occupies an increasingly important space in our day-to-day and it determines the way we interact with the people around us.

We can't accurately predict what the world will be like (or what we'll be like) in 20 years' time, but we do know that science and technology will play leading roles in its change.

In this respect, it's essential our children become familiar with its fundamentals from early on.

It is in this context that we created Tommy the Robot Game.

Tommy the Robot guides your children through the discovery of programming (software) and design. It teaches them that technology can be transparent, fun and accessible.

The freer knowledge is, the faster we progress.

We hope that your experience with Tommy is as fun and exciting as it was for us.

The Zyrobotics Team

WARRANTY PERIOD

The Product may be comprised of a number of different parts, and these parts may be covered by different warranty periods (hereinafter, the “Warranty Period”). The general Warranty Period is twenty-four (24) months.

To the extent permissible under the laws of the country, the Warranty Period shall not be extended, renewed or otherwise modified following the subsequent resale, repair or replacement of the Product by Zyrobotics.

However, any part(s) repaired or any products replaced during the Warranty Period shall be guaranteed for either the remainder of the original Warranty Period or a period of six (6) months from the date of repair or replacement, whichever is greater.

CLAIMING ON THE WARRANTY

If you wish to make a claim under the terms of this Limited Warranty, please send the affected Product or part, (if the Product is not affected in its entirety) to an authorised service agent of Zyrobotics. You can also call Support (charges may apply, depending on national rates or your service provider plan) in order to obtain more information on how to make a claim.

Any claims made under the terms of this Limited Warranty shall be subject to notification of the presumed defect on your part to Zyrobotics or an authorised service agent within a reasonable period of time following discovery of the said defect, and in any case, no later than the expiry date of the Warranty Period.

If you make a claim under the terms of this Limited Warranty, the following shall be duly forwarded: a) the Product (or the affected part) and b) the original receipt of purchase, clearly indicating the name and address of the vendor, the date and location of the purchase, the type of product and the serial number.

LIMITED WARRANTY/LIABILITY

Zyrobotics makes no warranty or representation, express or implied, concerning the product or its merchantability, fitness thereof for any purpose, or its non-infringement. Zyrobotics shall not be liable for special, indirect, consequential or punitive damages of any kind, whether or not caused by its negligence, and assumes no risk whatsoever as to the result of the use of the product either singly or in combination with other material. In the event that this disclaimer of liability is held by a court not to apply to buyer, Zyrobotics' maximum liability to buyer on any claim in any way connected with the sale or use of the product, whether liability arises in contract, from breach of warranty, in tort or otherwise, shall be limited to the product's invoice price.

TROUBLESHOOTING

If Tommy doesn't operate correctly, please use the following guide to determine the cause. If, after following this guide, your unit still doesn't operate, please send us an email.

Symptom

Tommy is not 'discoverable' during pairing

Possible Cause/ Remedy

- Ensure battery is charged.
- Ensure unit is awake by toggling on the on/off switch.
- Unit may be connected with another device , which is in range. Use ' forget t this device' in Bluetooth menu to make the unit available again.

Symptom

Tommy has been connected to this device before but won't connect now.

Possible Cause/ Remedy

- Re-connection should be automatic but if difficulties persist , try to ' forget this device' and then re-connect.

Quick Start Guide

Follow this guide step by step and start playing with your new robot!

How To Get Started.

CONNECTING TO YOUR DEVICE

Install the Tommy the Robot application on your Android tablet or smartphone. Then go the settings menu on your device and select Bluetooth to pair the Robot to your device.

Make sure Bluetooth is on.

Take the Robot out of its case and arrange its feet so that it can stand alone. Cut the Robot on. The on button is the topmost button on the back of Tommy the Robot.

Look for Zowie and select that unit to connect.

Tap on the name and the pairing process will begin. Enter the Bluetooth pairing code when asked: 1234.

It takes less than 20 seconds to connect, after which your device will state that the device is

Once your device says it is paired, return to the main screen and you are ready to start Tommy the Robot app.

Explore the world of Tommy on the website.

Discover new ideas and activities to get the best out of your robot.

Teach Tommy new skills through easy programming on website.

Instructions

INSTRUCTIONS AND SAFETY PRECAUTIONS FOR PARENTS

When using your Tommy the Robot please follow these safety recommendations:

- Parents or teachers must read all of the documentation included with this product.
- Do not use cables that have not been approved by the manufacturer, nor any damaged connectors or loose sockets.
- Do not bend or damage the micro USB cable. Do not touch the power cable with wet hands. Do not pull on the cable to unplug it from the computer or the electronics.
- It is recommended to use a micro USB cable of no more than 1.4m in length.
- Do not knock or drop Tommy.
- Handle and dispose of the consumables carefully.
- Ensure that the small parts, or any parts that could be dangerous for small children are kept out of their reach.
- Tommy must be charged using a micro USB charger of 5V and 1A. The toy should only be connected to protection class II equipment.



CHARGING TOMMY

Ensure that the battery is fully charged by plugging the charging cable into the port on the back of your Robot device and then into a computer USB port. For your convenience we have also included a small USB converter that allows the USB port to plug into a wall socket. The charging LED will illuminate yellow to show that charging is taking place. Once charged, the charging light will disappear.

- Zyrobotics shall not be liable for any change of battery to one of another manufacturer.
- Keep the toy and its accessories away from sources of heat and direct flames. Do not store or transport flammable liquids, gases or explosive materials in the same compartment as the Tommy or any of its parts or accessories.
- Ensure that the toy and its accessories do not come into contact with conductive liquids such as water.
- Replacing the battery with one that has not been approved by the manufacturer may cause it to explode.

WARNINGS

- Take care when touching the moving parts as injuries could be caused.
- Not recommended for children under 36 months.
- The accessories and the plastic pieces are not edible.
- This toy is intended for children above 8 years old.